

CA 1026 Firming Serum

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 1				
Deionised water	76.48			
Glycerine	5	Moisturizer	Glycerine	
Disodium EDTA	0.07	Chelating agent	Disodium EDTA	
Carpobol Ultrez 20	0.3	Gelling agent		
Phase 2				
Sodium Hydroxide (50% Soln.)	0.15	Neutralizer	Sodium Hydroxide	
Phase 3				
Transcutol CG	3	Activity Enhancer	Ethoxydiglycol	Gattefosse
Cn-PS2	1	Hydrating agent	Palmitoyl Hydroxypropyl Trimonium Amylopectine / Glycerine Crosspolymer (and) Phenoxyethanol (and) Methylparaben (and) Hydrogenated Lecithin (and) Ethylparaben (and) Butylparaben (and) Propylparaben (and) Isobutylparaben	Kobo
Pancogen Marine	3	Hydrolyzed Collagen	Soluble Collagen	Gattefosse
Kigelia Extract	10	Friming agent	Water (and) propylene Glycol (and) Kigelia Africana Fruit Extract	Gattefosse
Gs-VA100C	1	Promote Cell renewal	Butylene Glycol (and) Water (and) Palmitoyl Hydroxypropyl Trimonium Amylopectin / Glycerin Crosspolymer (and) Polysorbate 20 (and) Retinol (and) Phenoxyethanol (and) Hydrogenated Lecithin (and) Methylparaben (and) BHT (and) Ethylparaben (and) Butylparaben (and) Propylparaben (and) Isobutylparaben (and) BHA	Kobo
Total	100			

Process:

1. Dissolve Glycerine and EDTA into the water.
2. Then, disperse Ultrez 20 over the water. Let stand.
3. Use Phase 2 to adjust the pH of the Phase 1 within 6.8-7.2.
4. Finally, add in the ingredients in Phase 3 accordingly into Phase 1+2 with slow agitation to avoid bubble and stir until homogenous.

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.