

CA 1076 Collagen Booster

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 1				
Emulium Kappa	6	O/W emulsifier	Candelilla/Jojoba/Rice Bran Polyglyceryl-3 Esters (and) Glyceryl Stearate (and) Cetearyl Alcohol (and) Sodium Stearoyl Lactylate	Gattefosse
Labrafac CC	7	Emollient	Caprylic/Capric Triglyceride	Gattefosse
Microcare PM5	0.8	Preservatives	Phenoxyethanol (and) Methylparaben (and) Ethylparaben (and) Propylparaben (and) Butylparaben (and) Isobutylparaben	Thor Specialties
DPPG	7.5	Emollient	Propylene Glycol Dipalmonate	Gattefosse
Cetyl Alcohol	4	Thickener	Cetyl Alcohol	
Isostearyl Isostearate	4	Emollient	Isostearyl Isostearate	Gattefosse
Geleol Pastilles	2	Thickener	Glyceryl Stearate	Gattefosse
Lipocire A	3.5	Thickener	Hydrogenated Palm Kernel Glycerides (and) Hydrogenated Palm Glycerides	Gattefosse
Phase 2				
Deionized Water	57.35			
Disodium EDTA	0.05	Chelating agent		
Lucentite SWN	1	Gelling agent	Lithium Magnesium Sodium Silicate	Kobo
Phase 3				
Glycerine	3	Humectant	Glycerine	
Xanthan Gum	0.2	Gelling agent	Xanthan Gum	

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 4 Hematite	1	Collagen Booster	Hematite extract	Gattefosse
Gatuline Expression	2	Anti-wrinkle active	Alcohol (and) Water (and) Acmella Oleracea extract	Gattefosse
PF. JG 10266	0.6	Fragrance		Technico Flor
Total	100			

Process:

1. Dissolve Disodium EDTA and disperse Lucentite SWN into deionized water.
2. Premix Phase 3 and add Phase 3 into Phase 2 with moderate stirring speed.
3. Add Phase 1 heated to 75-80°C into Phase 2+3 heated to 75-80°C with moderate agitation.
4. Cool while stirring.
5. Add all the ingredients in Phase 4 into Phase 1+2+3 at 45°C and stir until homogeneous.
6. Complete cooling.

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.