

CA 1085 Vitamin E Serum

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 1				
Deionized Water	58.6			
Disodium EDTA	0.1	Chelating agent	Disodium Ethylenediamine Tetraacetic acid	
Ultrez 20	0.3	Gelling agent	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	
Phase 2				
NaOH (50% Soln)	0.5	pH Neutraliser	Sodium Hydroxide	
Phase 3				
Cn-PS2	1	Hydration agent	Palmitoyl Hydroxypropyl Trimonium Amylopectin/ Glycerine Crosspolymer (and) Phenoxyethanol (and) Methylparaben (and) Hydrogenated Lecithin (and) Ethylparaben (and) Butylparaben (and) Propylparaben (and) Isobutylparaben	Kobo
Gatuline RC	2	Nourishing agent	Water (and) Fagus Sylvatica extract	Gattefosse
Fresh Cell Vegetal	5	Soothing agent	Cucumis Sativus (Cucumber) Fruit extract (and) Water (and) Propylene Glycol	Gattefosse
Transcutol CG	3	Activity Enhancer	Ethoxydiglycol	Gattefosse
Extrait Original Orange Bio	20	Orange Fruit Water	Orange Fruit Water	Gattefosse
Corum 8803	2.5	Initiates the stimulation of collagen synthesis	Glycerine (and) Palmitoyl Oligopeptide	Corum
Gs-VE	5	Vitamin E	Palmitoyl Hydroxypropyl Trimonium Amylopectin/ Glycerine Crosspolymer (and) Phenoxyethanol (and) Tocopherol (and) Methylparaben (and) Hydrogenated Lecithin (and) Ethylparaben (and) Butylparaben (and) Propylparaben (nad) Isobutylparaben	Kobo
Corum 8804	1	Skin Repair active	Glycerine (and) Palmitoyl Tetrapeptide-3	Corum

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 4				
Microcare MTP	0.2	Preservatives	Methylisothiazolinone (and) Methylparaben	Thor Specialties
Solubilisant Gamma 2429	0.6	Solubilizer	PEG-40 Hydrogenated Castor Water (and) Polysorbate-20 (and) Water (and) Octoxynol-12	Gattefosse
PF. RS 23787	0.2	Fragrance		Technico Flor
Total	100			

Process:

1. Dissolve Disodium EDTA and disperse Ultrez 20 over deionized water. Let stand.
2. Add Phase 2 into Phase 1 and stir homogenously.
3. Then, add all the ingredients in Phase 3 into Phase 1+2 and stir until homogenous.
4. After that, premix all the ingredients in phase 4 and stir until homogenous.
5. finally, add Phase 4 into Phase 1+2-3 and stir until homogenous.

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.