

CA 1093 Genoprotective Cream with SPF 15

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 1				
Emulium 22	4	O/W emulsifier	Tribehenin PEG-20 Esters	Gattefosse
TNP50VTTS	10	TiO ₂ dispersion	C12-C15 Alkyl Benzoate (and) Titanium Dioxide (and) Alumina (and) Polyhydroxystearic Acid (and) Isopropyl Titanium Triisostearate/ Triethoxycaprylsilane Crosspolymer	Kobo
BC Volatile 5	5	Feeling agent	Cyclomethicone	Basildon
Siltech CE-2000	2	Feeling agent	Trioctyldodecyl citrate	Siltech
Phase 2				
Deionised water	26.7			
Ultrez 20	0.3	Gelling agent		
Phase 3				
Xanthan Gum	0.3	Gelling agent		
Glycerine	5	Moisturizer		
Phase 4				
NaOH (50% Soln.)	0.3	Rheology modifier		
Phase 5				
Zincite	5	Genoprotective agent	Water (and) Smithsonite extract	Gattefosse
Extrait Originel Apple	40	Fruit water	Apple Fruit water	Gattefosse
Microcare MTP	0.2	Preservative		
Perfume	0.2	Fragrance		Technico Flor
BPA-500	1	Filler	Polymethyl methacrylate	Kobo
Total	100			

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.

Process:

1. Predisperse Xanthan Gum into Glycerine and stir until homogenous.
2. Add in Phase 3 into Phase 2 and stir until homogenous.
3. Add in Phase 1 heated to 75-80°C into Phase 2+3 heated to 75-80°C and stir rapidly for about 10 minutes.
4. Add in Phase 4 into Phase 1+2+3 and stir until homogenous.
5. Cool while stirring.
6. Add in the ingredients in Phase 5 into Phase 1+2+3+4 and stir until homogenous.
7. Complete cooling.



This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.