

CA 1104 Genoprotective Cream

Ingredients	%(w/w)	Functions	INCI designation	Supplier
Phase 1				
Emulium 22	6	O/W emulsifier	Tribehenin PEG-20 Esters	Gattefosse
TNP50VTTs	10	TiO ₂ dispersion	C12-C15 Alkyl Benzoate (and) Titanium Dioxide (and) Alumina (and) Polyhydroxystearic Acid (and) Isopropyl Titanium Triisostearate/ Triethoxycaprylsilane Crosspolymer	Kobo
BC Volatile 5	5	Feeling agent	Cyclomethicone	Basildon
TNP50ZSI	15	Feeling agent	C12-15 Alkyl Benzoate (and) Zinc Oxide (and) Polyhydroxystearic Acid (and) Triethoxycaprylsilane	Kobo
Phase 2				
Deionised water	56.7			
Ultrez 20	0.3	Gelling agent		
Phase 3				
Xanthan Gum	0.3	Gelling agent		
Glycerine	5	Moisturizer		
Phase 4				
NaOH (50% Soln.)	0.3	Rheology modifier		
Phase 5				
Microcare MTP	0.2	Preservative		
Perfume	0.2	Fragrance		Technico Flor
MSS-822	1		Polymethyl Methacrylate	Kobo
Total	100			

Process:

1. Predisperse Xanthan Gum into Glycerine and stir until homogenous.
2. Add in Phase 3 into Phase 2 and stir until homogenous.
3. Add in Phase 1 heated to 75-80°C into Phase 2+3 heated to 75-80°C and stir rapidly for about 10 minutes.
4. Add in Phase 4 into Phase 1+2+3 and stir until homogenous.
5. Cool while stirring.
6. Add in the ingredients in Phase 5 into Phase 1+2+3+4 and stir until homogenous.
7. Complete cooling.

This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It's offered solely for your consideration, investigation and verification.